

OPERATION & MAINTENANCE MANUAL FOR ECLIPSE # 88WC SAMPLING STATION

DESCRIPTION

- A. The sampling stations are Eclipse Model #88WC, as manufactured by The Kupferle Foundry Company, 2511 North 9th Street, St. Louis, MO 63102. Phone 800-231-3990.
- B. Sampling stations are above ground type with 1 MIP Inlet & 1" FIP Threaded Outlet, with a 1/8" Sampling Bibb located below the outlet. All operating parts of the sampling station can be serviced or replaced without digging up or disturbing the supply line connection.
The #88WC is designed for warm climates and offers no freeze protection.

OPERATION

- A. Sampling station is manually operated by turning the lever type handle on the 1" ball valve counterclockwise to the on position. Sampling station is closed by turning the handle to the right or clockwise. If desired, the female threads at the outlet allow the operator to attach a 1" hose and adapter to divert the water.
- B. The 1/8" Sampling Bibb allows the operator to collect a sample with or without the water flow in motion.

PARTS RELACEMENT

- A. Replacement parts may be obtained from The Kupferle Foundry Company, 2511 North 9th Street, St. Louis, MO 63102. Phone 800-231-3990.
- B. There is no routine maintenance required for the #88WC Sampling Station.